Configuring A Device

Navigation

This can be accessed via the Device Dashboard page.

Overview

On this page, device parameter information is displayed and can be interacted with. This page is split up into 3 tabs, namely:

- 1. The Overview Tab
- 2. The View Tab
- 3. The Edit Tab

The Overview Tab

The Overview tab contains parameter cards and chips. These can be filtered by status using the drop down menu.

Parameter Cards And Chips

Parameter cards and chips both display information such as:

Parameter readings

The current value of the parameter will be displayed here. The format of the value is dependent on the currently selected template. In the case of chips, icons will be displayed here in specific cases.

Parameter statuses

This is indicated with the status below the reading, as well as by the color of the card/chip.

Parameter alert configurations

This is indicated by the bell icon ,which indicates that an alert group is set, and a monitor icon, which indicates that server alerts are enabled. The number displayed indicates how many rules are currently set on the parameter.

Editing Parameters

Clicking on any card or chip will select it. This can be done for multiple cards or chips.

The selected cards or chips will then turn pink to indicate it has been selected and a menu will open on the right hand side of the screen.

Clicking on the pencil icon will allow you to edit the parameter.

Editing Details

Here you can edit the parameter's name, and template.

Templates define how the reading will be formatted for display on the dashboard. For example, when editing a temperature probe, you can select between degrees Celsius or degrees Fahrenheit.

Editing Rules

Alerts can be configured by clicking on the rules tab. Rules can be applied to a parameter to configure the server to dispatch alerts when the specified condition triggers.

The setpoint rule can be applied to a parameter to configure the server to dispatch alerts when the configured threshold is exceeded.

To configure the setpoint rule follow the following steps:

1. Click the plus button and select the rule named setpoint.

Rules Add New Rule	+	
Add New Rule		
Rule	^ .	
Setpoint Save		

2. Configure the alert by adding a delay. Delays determine the duration at which the value remain above or below the given configuration before an alert is dispatched.

	••	-
Fu	11	t.
_\		L.

7

Details	Rules	
dd New Rule		^
Rule		
Setpoint		-
Name *		
Setpoint		
Delay *		0
Required		
Alert group		-
onfiguration		
Enable HHL Maximum	Enable MinMax	
		~
Cancel	ubmit	

3. Select an alert group.

Edit			
Details	Rules		
Add New Rule			^
- Rule			
Setpoint		-	l
Name *			
Setpoint			
Delay *		\$	
Required			
Alert group		•	
Configuration			
Enable HHL	nable MinMax		
ANGALL KILL			\checkmark
Cancel	mit		

4. Adding the alert conditions. Setting a minimum and maximum value will allow you to receive alerts when the sensor value goes above or below the set value. This allows you to define a normal working value range for your sensor, so that you can receive alerts if these are surpassed. Setting a LowLow and HighHigh will allow you to receive alerts immediately if critical values are reached. These alerts are regarded as critical and will ignore any delay set.

_	_	٠.	
-	~		
_	u		•

7

Enable HHL Enable MinMax		
8	\$	
Minimum		
2	$\hat{}$	
Low Low		
0	0	
High High		
15	0	
Alert Type		
Server Alert	*	
] Back In Range Alert		~
Canaal		

5. After you are done click save, then click submit.

Edit

Details	Rules		
~ 		· /	^
Minimum			
2		0	
Low Low			
0		$\hat{}$	
High High			
15		$\hat{}$	
			1
Alert Type			
Server Alert		-	
Back In Range Alert			
T Enable Alert Schedu			
Cancel Save			,
Cancel Submit			

Graphing Parameters

k.

Parameters can also be graphed by clicking the graph icon on the selection menu.

On this screen you can graph your parameter's data according to various time-ranges.

Time ranges can be selected via the specified range drop down menu. Selecting 'Custom' allows you specify your own time range, while selecting 'Snapshot' allows you to select a specific date and time.

The graph type can also be changed from the drop down menu.

The View Tab

The View tab contains read-only parameters displayed within a table. The table displays read-only parameter values, short code and descriptions. These are grouped and displayed by parameter type.

 Mythopositine 			
	A tentent 3 terrated out 5 tentes		
Caribana (frankes Plan fills		
•	. 100 A		
Income interest	- 100	Best June	Description
0 %	08w		
	274%	10	Default Pater
🖀 landaquada	- 1046		Regulation Protect
	- 185.	14	Ngnai
Za Armen			(substrued
	07	11	Compressor Mater
	64 C	28	Certrain Nation
		26	Autilities
	*	181	Trapatropic annual
	3	58E	Ourspeace way dated
	4		Default when similar
	4	-484	Fair ratio status
	A	-48	And alog mean (et a set)
			Investigation (
fa men			

These can be searched through from the search bar and can be filtered by type using the drop-down menu.

The Edit Tab

The Edit Tab contains contains editable parameters displayed within a table. The table displays editable parameter values, short code and descriptions. These are grouped and displayed by parameter type.

a Mylicycoline				•
ð	A testinet 3 testimitations 5 testine			
E Continued	Reprises Files Soll			
8 mm	trach			8 8 0
E level	Tabar	Rev Tolan	Unit Dean	Providen and
0 ~	Pode			
4 mm	1		4	Protectory
E integrals -				Salart price displayed
			4	NAME OF A POST O
A. Amor				
	1			Technologi ()extrat_1 - district
	1		AD	Collection of protect
	4		A2	Collection of police 1
				Collimation of problem
	Aum			
	1			April and the differential
	4		*	Dytaliyasi seligentin
[+ isset				Terrystopp N * 110000 1 P

These can be searched through from the search bar and can be filtered by type using the drop-down menu.

Editing Parameter Values

Entering a value into the 'New Value' field will allow you to assign a new value to the parameter. Doing so will also highlight the field in green if it is a valid value. The save button will allow you to save this value once complete. Multiple fields can be edited simultaneously. Once complete, click the Save button on the right side of the screen, to save your changes.

· Myticpostre				
0	A tenter 3 terraterior 5 second			
E Contract	Barries Ver 5.8			
é	such .	4 v		
E ferre	- 10a	Res Tolan	Dark Deer.	location (
B ***	Poster			
4 mm	1		4	Pode resummer delity
E integrals	1 A 4	1		Salari pola displayad
				Next TAY THIS IS
A trees				
			*	Demetanel Dextent/1 - Rated
	1		AD	Collimation of probe 1
			A0	Collimation of protinc I
				Cultoring of protect
	Ann			
	1			April and the differential
				Dytal year and proton
E+ taund				nerveral at a constant ()

Setting Up Board Alerts

Alerts determined by the controller can be configured by clicking on the bell icon. This will bring up the edit dialog for the Defrost Probe. Adding the SMRT Cold Board alert rule to the Defrost Probe allows alerts to be dispatched from the server when one or more controller alarms get triggered.

To configure this rule follow the following steps:

1. Click the plus button and select the rule named Board Alert.

Rules	
Rules	H
Add New Rule	
Rule	
Setpoint	
Board Alert	

2. Configure the alert by adding a delay. Delays determine the duration at which the value remain

Submit

Cancel

above or below the given configuration before an alert is dispatched.

Details	Rules		
Add New Rule			
Rule			
Board Alert		*	
Nome #			
Name*			
Delay *		0	
Required			
Alert group		•	
Danformation			
configuration			
Enable HHL	Enable MinMax		

3. Select an alert group.

.

4

_		•	
-	~		٠
			н
_	-		•

7

Details	Rules	
Add New Rule		^
Rule		
Board Alert		•
Name *		
Board Alert		
Delay *		٥
Required		
Alert group		-
Configuration		
Enable HHL	Enable MinMax	~
Cancel Sub	mit	

4. After you are done click save, then click submit.

Edit

R.

Alert Group 1	× 🕶	^
onfiguration		
Enable HHL Enable MinMax		
0	\sim	
High High		
10	< >	
Alert Type		
Server Alert	*	

Alerts will now be dispatched to the users in the alert group when the controllers' alarms are triggered.



Last update: 2025/05/01 12:13

k

