# Allocating A User To A Device Pool

## **Navigation**


Allocating users to device pools can be accessed from the Allocate Users page.

## **Overview**

Here, users can be allocated to specific device pools. If the user is of role User or Manager, they will only be able to view devices within the device pools which have been allocated to them.

Simply select the device pools you wish to allocate to the selected users and submit when done. Multiple device pools can be selected.

### User Devicepool Mapping



#### From:

https://docs.myfridgeonline.com/ - MyFridgeOnline

#### Permanent link:

https://docs.myfridgeonline.com/user manual/devicepools/allocate user



