

# Carel Controller Configuration

Before installing your **SMRTCold** system, ensure your **Carel controller** is correctly configured. Incorrect settings can lead to setup failures or communication issues.

## Setting Overview

The following parameters need to be configured on your Carel controller:

- **BMS Network Address:** 1
- **BMS Configuration:**
  - Stop Bit: 1
  - Parity: None
- **BMS Baudrate (bit/s):** 19200
- **BMS Protocol:** Modbus

## Walkthrough

Follow these steps using the **Carel Applica** app:

### 1. Install Carel Applica

Download and install the Carel Applica mobile application:

□ <https://www.carel.com/apps>

### 2. Connect to Your Controller


- Open the app and connect to your Carel controller using Bluetooth or NFC (depending on model).
- You may need to select the account/profile "Service"
- When prompted for a password input "22"

### 3. Access the Parameters

- Open the main menu.
- Navigate to the **Parameters** section.


### 4. Configure Connectivity Settings

From the top bar, select **Connectivity**.




## 5. Set Parameters


- **BMS Network Address: 1**




- **Stop Bit:** 1
- **Parity:** None



- **Baudrate:** 19200 bit/s



- **Protocol:** Modbus



Ensure each setting is confirmed after changing.

## ☐ Completion

Once all settings are correctly applied, your Carel controller is ready for SMRTCold integration.

You may now proceed with the SMRTCold installation.

---

If you encounter any issues, verify that all communication settings exactly match the configuration above.

From:  
<https://docs.myfridgeonline.com/> - **MyFridgeOnline**

Permanent link:  
[https://docs.myfridgeonline.com/products/smrtcold/carel\\_controller\\_configuration\\_guide](https://docs.myfridgeonline.com/products/smrtcold/carel_controller_configuration_guide)

Last update: **2025/08/07 07:53**

